



AI TOY

User Manual




User Guide

Power on/off operation

1. Power on: Press and hold the "on/off" button on the back for three seconds, and your eyes will light up to successfully power
2. Shutdown: Press and hold the "on/off" button on the back for three seconds, and the eyes will turn off to successfully shut down.

Network Configuration OR re-networking

re-networking: Click three times





APP Download and Use

1. Search for tuyasmart or smartlife on Google Play or Apple App Store,
2. After entering the App, follow the Ai Cat accordingly.
3. You can adjust the volume and character of the Ai Cat through the app.




Network Configuration


1. Turn on your phone's WiFi and connect it in advance (WiFi password is required for the subsequent network configuration process),And confirm that the WiFi name is in the 2.4G frequency band (usually routers support 2.4G, such as "Only5GWiFi "or" 2.4G and 5GWiFi with the same name "are not supported)
2. Turn on the device and enter the Tuya applet
3. Enter the app and click "+"in the upper rightcorner of the home page




4. Click "Add Device"




5. Connect your product to the product




6. Connect to the same network as the phone




7. Click to enter edit mode



8.Can adjust volume or edit/switch roles



9. Enter the editing role to switch between language, tone, and model




Product usage instructions

Dialogue Mode: Upon successful network connection, the device automatically enters dialogue mode by simply clicking the AI Cat 's right ear button. To interrupt while the AI Cat is speaking, press the right ear button again to pause the dialogue.

When Ai Cat' s eyes display a facial expression on the right side, it indicates that Ai Cat is listening to what you are saying.

You can wake up the AI Cat by saying any of the following wake words: "Hi, Tuya," or "Hey, Tuya."

The right ear button serves as the interruption/wake-up key.




Ai Cat is listening to what you are saying



Expression Trigger: When you say phrases expressing emotions such as "I'm so happy," "I'm so angry," "I'm so disappointed," "I'm so sad," or "I'm so surprised," the toy will provide corresponding facial expression feedback.



Petting Mode: The petting mode activates automatically upon powering on. Gently pet the doll's head to trigger one of three different sound effects. This feature remains available even during conversations.



Charging requirements

1. Connect the charging cable to the charging port of this product, and use a legitimate charger with a rated output of 5V2A and a CCC certification (which would need to be purchased separately) to charge the product.
2. Fully charging typically takes around 2 hours (there might be slight variations due to various factors).
3. During the charging process, the light on the right side of the Type-C charging port will turn yellow when charging is in progress and turn green when the charging is complete.
4. Do not charge the device continuously for more than 8 hours. Ensure that someone is present while charging. Do not charge the device when you are away or have been absent for an extended period.

Product Information

AI Curious Cat Robot Information

product name	AI Curious Cat Robot
Product material	Plush fabric made of 100% polyester fiber, plastic core, electronic components
product size	90*90*90mm tail 100mm
Charging input	5V 2A
cell voltage	3.7-4.2V
maximum power	5W
Type of battery	lithium cell
battery capacity	1000mAh

AI Scruffy Cat Robot Information

product name	AI Scruffy Cat Robot
Product material	Plush fabric made of 100% polyester fiber, plastic core, electronic components
product size	110*105*105mm tail 110mm
Charging input	5V 2A
cell voltage	3.7-4.2V
maximum power	5W
Type of battery	lithium cell
battery capacity	1000mAh

Safety precautions

1. This product is equipped with a built-in lithium battery. The device should be used within the temperature range of 0°C to 40°C. Do not place the product in extremely high-temperature environments. Ensure that it is kept away from fire sources or other heat-emitting objects. Do not bring it close to a fire source. Avoid any collision, impact, squeezing, or piercing. Do not attempt to disassemble, repair, or modify the product on your own. Do not expose the battery to extremely low atmospheric pressure, as this could lead to the battery exploding or the leakage of flammable liquids and gases.
2. Do not use the charger to charge this product in damp locations (such as near sinks, bathtubs, or bathrooms).
3. Children should be supervised and guided by an adult while using the product, and the adult should be responsible for the user's safety. Before use, please verify that the product's appearance is intact, the installation is correct, and the machine is functioning normally. If any issues arise, please contact customer service.
4. Please handle the packaging of this product properly to prevent infants from coming into contact with it, which could lead to suffocation accidents. Do not use the product or its accessories when they are damaged or broken, and do not clean the product while it is powered on or charging.
5. Please regularly inspect this product. If you notice any abnormalities with the charging process or charging cord, discontinue use immediately. Failure to do so may result in electrical leaks, short circuits, or even fires.

Cleaning Method

1. This product is not waterproof. Do not wash it with water or submerge it in water.
2. Do not use saltwater, hot water, or cleaning agents containing bleach, strong acids, or bases as cleaning agents.
3. Please turn off the device and clean it first. For daily use, you can use a soft cloth dampened with tap water. After thoroughly wringing it out, gently wipe the plush surface clean. Once the cleaning is complete, make sure to use a dry paper towel to lightly press out any excess moisture. Allow it to air dry naturally before using a small metal comb to tidy up the plush surface.
4. If you encounter stubborn stains, please contact our official customer service for more guidance on cleaning.